



SPARTAN GEAR

LOCHOS 2

WIRED MECHANICAL TENKEYLESS
GAMING KEYBOARD

SOFTWARE MANUAL

SOFTWARE MANUAL

The software manual is available in following languages

EN

GR

DE

FR

IT

BG

RO

TO DOWNLOAD

enter the “Downloads” section on our website

www.spartangear.eu

INSTALLATION INSTRUCTIONS:

- ❑ Plug the keyboard into the PC.
- ❑ Use the CD to install the software (alternatively download the software from www.spartangear.eu).
- ❑ Once you complete the installation, right click the icon  that will appear on your desktop and click open.

PROGRAMMING INSTRUCTIONS:

You can program and customize up to 50 different profiles. Keys' function programming and light customization instructions are the same for each profile.

Profile settings:

- ❑ **Adding profile:** ① Click the “+” icon on the right side to add a profile.
- ❑ **Modify profile name:** Type the name you want and click  to store.
- ❑ Use the following icons to **export**, **copy**, **reset** default, **delete*** or **import** ② any of the active profiles.

*One profile must always remain active.



LED Light programming:

To enable lighting feature and programming, select the **“Light settings”** option.

- ❑ Choose between 19 different LED light combinations from the drop-down list.
- ❑ Adjust, if needed, the Brightness and/or Speed from the bars.
- ❑ Customize different colors and running directions using the colors available.



Customized LED light combinations

Fixed Color option

Choose **“Fixed Color”** option to assign a color to all keys at the same time.

- ❑ Select the color of your choice and click **“OK”**.
- ❑ All the keys will now appear with the chosen color.

To remove or change the color of a key:

- ❑ Click on any key to remove the assigned color.
- ❑ Choose another color from the “**Color**” option and click again any key to assign.

Custom Color option

Choose “**Custom**” option to assign a color to one key at a time. You can customize up to 5 different key groups.

- ❑ Select the color of your choice and click any key or keys you want to apply it.
- ❑ The selected key or keys will now appear with the chosen color.
- ❑ Repeat the same process to apply a different color to any other key or keys.

To change the color of a key:

- ❑ Click on the key to remove the previously assigned color.
- ❑ Choose another color and click again the key to assign.



Key Assignment feature

To enable key assignment feature and programming, select the **“Button settings”** option.

- 1 Click any key you want to program.
- 2 Click the list and select the function you want to set.



You can choose one from the below functions:

- **Default Function:** Keep current default function
- **Mouse Key:** Set the key as mouse function.
- Click the key you want to assign, then choose **“Mouse Key”** list.
- Click **“Please select a function”** to choose between

LB: Left button.


MB: Middle button.

RB: Right button.

Forward: Forward.

Backward: Backward.

Click the **save icon**  to store.



The fire key: Set any key as “fire key” function

- Click the key you want to assign, then choose “The fire key” list.
- Type interval time and the number of keys and click **save icon** to store your setting.




Standard keyboard button: Set any key as a key combination. For example, set “F” key as “CTRL +C” function.

- ❑ Click the “F” key then choose “Standard keyboard button” list.
- ❑ Choose “CTRL”
- ❑ Type “C” in the frame
- ❑ Click **save icon**  to store the setting.




Multimedia Key: Set any key as a multimedia key function.

- ❑ Click the key you want to assign, then choose “Multimedia Key” list.
- ❑ Choose from the drop-down list the multimedia function you want to assign.
- ❑ Click **save icon**  to store the setting.




System Function: Set any key as “Power”, “Sleep” or “Wake up” function

- ❑ Click the key you want to assign, then choose “System Function” list.
- ❑ Choose from the list the function you want to assign.
- ❑ Click **save icon**  to store the setting.



Macro Function:

- ❑ Before setting any key as macro function, you should first create a macro. Please use the instructions in the “**Macro feature**” section of the manual.
- ❑ Set any key as macro function
- ❑ Click the key you want to assign, then choose “**Macro Function**” list.
- ❑ Choose “**macro_1**” under “**Assigned Macros**” list!
- ❑ Choose from the list the function you want to assign.
- ❑ Click **save icon**  to store the setting.



Office Key: Set any key as office using function.

- ❑ Click the key you want to assign, then choose “**Office Key**” list.
- ❑ Choose from the list the function you want to assign.
- ❑ Click **save icon**  to store the setting.

Macro feature:

How to create a macro

- ❑ Click **“Macro Management”**.
- ❑ Click **+** button to create a new macro.
- ❑ Enter the name of your choice for the macro and click .
- ❑ Choose **“Fixed Time(ms)”**, then click **“REC”** to record.
- ❑ Select the function you want from the **“Keystroke”** list.
- ❑ When you complete your selection click **“Stop”**.
- ❑ Change the **“Delay(ms)”** if needed.
- ❑ Insert the mouse action you want.

You can add as many macros as you need.



Use any of the buttons below to:

- ❑  Rename
- ❑  Add macro setting.
- ❑  Save
- ❑  Modify the macro setting name.
- ❑  Delete
- ❑  Upload the saved macro setting.

- Use the arrow keys to navigate through your different macros.
- Delete the selected macro setting.
- Clear all macro settings.

Other Settings

USB report rate setting


USB report rate refers to the number of times the keyboard sends the input data to the **PC**. **Spartan Gear Lochos TKL RGB** has the option to choose from a polling rate of **125/250/500/1000Hz**. You can choose the polling rate based on your needs.

“Windows Lock” icon.

Click the **“Windows Lock”** icon to lock and unlock the **“Windows Lock”** key.

“Exchange key” icon.


Use that key to switch between **WASD** keys and arrow keys.





explore our full range of products at

www.spartangear.eu



Disclaimer: Spartan Gear is an independent brand name and has not been authorized, sponsored or otherwise approved by any manufacturer, company or brand. All trademarks, company and brand names used, are the property of their respective owners; Spartan Gear (*and Enarxis Dynamic Media Ltd.*) disclaims any ownership of such Registered Trademarks & brand names as well as any association with them and their respective owners. They are used here merely for delivering information.